



## **CHAFING DISH INSTRUCTION AND TIPS SHEET**

**\*CHAFERS WILL ONLY KEEP FOOD WARM\***

1. Chafing dish rentals include frame, lid, water pan, food pan and 2 sternos.
2. Fill the water pan ½" – 1" with HOT water.
3. Transfer prepared food into the food pans or you may use the food pan for cooking.
4. Place food pan within the water pan.
5. Open the two sterno cans and light with a match. They will burn for about 2 hours.
  - Extra sterno cans may be purchased.
6. Place cover over chafer to keep the food warm.

**\*\*CAUTION: HOT STEAM AND MOISTURE COLLECT UNDER THE LID WHILE IN USE. USE CAUTION WHEN OPENING THE LID \*\***

7. Sterno cans may be discarded after use, but sterno holders must be returned
8. Please discard left over food before returning the chafing dish.